
OPSISMART CALL MAX User Manual - EN





other PAPER PAP 22





FOLLOW THE INSTRUCTIONS OF YOUR COUNTRY

INSTRUCTIONS

How to wear the watch:

wear the device approximately one finger width from the carpal bone and place it in a comfortable position as shown in the photo. Wear the device a little tighter when using the heart rate monitor





Charging instructions
Charge the device before use.
To recharge the device, insert the USB port into a charger (5V---- 1A) or PC and correctly position the other end of the cable on the back of the smartwatch.



Notify:

DUse the charger only on a flat and stable surface.

- ²⁾ If there is an obstacle between the smartwatch and the charging cable, the smartwatch may not charge properly.
- ³⁾After charging the smartwatch, disconnect the power (do not leave the device charging for whole nights). To avoid damaging the device, use only the supplied cable.
- 4) Do not use if the charging device is damaged.
- 5) Unplug the charging device when cleaning the smartwatch, during a thunderstorm or during

a prolonged period of non-use.

- 6) Do not attempt to disassemble or modify the smartwatch and charging cable.
- 7) Do not twist or pinch the charging cable.
- ⁸⁾Do not attempt to remove or replace the battery. The substances contained in this product and the battery can cause damage to the environment or health. Please dispose of it properly. (Battery Directive 2006/66/EC)
- 2. Download the app

Scan the following QR code to download the app and the multilingual manual:

3. Bluetooth connection






Note:

Before connecting the device, make sure the battery is fully charged and the Bluetooth of the smartphone is turned on.

Before pairing the device make sure that a previous connection is not already active; if necessary, disconnect the previous connection and re-pair exclusively through the app.

Make sure that the distance between the smartphone and the smartwatch is not too great and that there is no interference between the two devices.

Some functions and/or features may not be available for all smartphones (Android and Apple) on the market.



1. Power on/off: long press to power on/off the device; short press to turn on/off the screen. 2. Sensor (on the back)

3. Charging slot (on the back)

4. Sport menù

Actions:

Swipe left/right ones menu



and up/down to swipe through the different items

5. Quick menu

Scroll down to view the different icons to click for quick access to the chosen section.

To activate call function, click only on the icon to automatically synchronize the function between the two devices.

6. Main Menu and Functions

Choose the functions to include in the main menu by clicking on the "+" button.

These functions cannot replace medical instruments. This product is not a medical device. It must not be used for any diagnosis or other medical applications.

Call function: To activat and use the call function, call log, numeric keypad and contacts.

Voice Ass.: Allows you to interact with your smartphone via voice commands.



Configure your smartphone with your favorite voice assistant.

Steps: Measuring distance, steps and calories. The stats will reset to zero at the end of the day.

Sleep monitor: View sleep monitor data. The smartwatch can record the quantity and quality of sleep divided into deep and light sleep.

Heart rate: Measurement of heartbeats.

Blood Pressure: Blood pressure measurement. Tests your current blood pressure and records the blood pressure results of the last seven readings.

Oxygen saturation: Measurement of Oxygen saturation. Tests current blood oxygen levels and records the results of the last seven readings.



Sport: Click on the screen to choose the desired sport

(more than 80 types of sport). The smartwatch will show the last measurement. N.B .: press the side button for Pause/Stop

Weather: It will show the weather forecast for today and next day. They will update automatically after connecting to the app.

Remote camera: After connecting, you can take photos by pressing the button on the smartwatch.

Remote Music player: After connecting, you can listen to your favorite music.

OPS! Ai: After connecting, you can ask the virtual assistant for information to receive immediate answers.

Ai Watchface: After connecting, you can ask the virtual assistant to generate a watchface following the requested theme.









Notifications: It will show the latest 5 notifications received from Twitter, Facebook, Whatsapp and messages.

N.B .: You can activate/deactivate this function via app.

Other functions: Stopwatch, Alarm and reminder, Timer, Sedentary reminder, Drinking reminder, Wrist sense, 5 preset Watchfaces + 1 editable Watchface + Watchfaces downloadable via app.

7. Troubleshooting

- I can't connect the smartwatch

¹⁰ Check that the GPS and Bluetooth of the smartphone are turned on.

²⁾ Make sure that the smartwatch and the smartphone are not too farapart. The connection must be made within 10 meters.

³⁾ Check if the smartphone is in airplane mode. In airplane mode, the smartwatch cannot be connected.

⁴⁾ Make sure that the smartwatch is not linked to another account or smartphone.

⁵⁾ Make sure your smartphone's operating system is Android 5.0 or later or iOS 9.0 or later.

⁶⁾ Make sure that a previous connection is not already active; if necessary, disassociate it and re-pair it exclusively through the app.

- I can't synchronize the clock data

¹⁰ Check that the GPS and Bluetooth of the smartphone are turned on.

²⁾ Make sure that the smartwatch and the smartphone are not too far apart. The connection must be made within 10 meters.

³⁾ Check if the smartphone is in airplane mode. In airplane mode, the smartwatch cannot be connected.

⁴⁾ Make sure the smartwatch is connected to the smartphone via the app.

- I can't get notifications

1) Make sure that the notification permissions on the app are active. 2) Make sure that the smartwatch and the smartphone are not too far apart. The connection must be made within 10 meters.

The alarm/schedule reminder does not work

Make sure the settings have been "saved" after they have been changed in the app.

The heart rate value is not accurate or cannot be detected

Make sure the heart rate sensor is clean and wear the device securely. Do not move during the survey, sit down and maintain a correct position in order to have a more accurate heart rate value.

MODEL: OPSCALLMAX Description: Smartwatch

We, DIFFUSIONE OROLOGI S.R.L. We declare under our sole responsibility that the product to which this document refers complies with the following standards:

SAFETY EN IEC 62368-EMC 1:2020+A11:2020 ETSI EN 301 489-1 V2.2.3 (2019-11) TSI EN 301 489-17 HEALTH V3.2.4 (2020-09) EN 55032:2015+A1:2020 EN 55035:2017+A11:2020 EN 300 328 V2.2.2 (2019-07) EN 62479:2010